



PROWEAR

WWW.PROWEAR.CO.NZ

Name: _____ Phone number: _____ Male / Female

Height (CM): _____ Weight (KG): _____ Glove Size: _____ Boot Size:(US) _____


Arm Restraint D Rings: Yes/No Shiny Nomex / Non Shiny Nomex NOT AVAILABLE FOR ALL COLOURS

One piece suit Two piece suit 1 Layer 2 Layer 3 Layer 5 Layer

SFI Rating: 3.2A/5 3.2A/10 3.2A/15 3.2A/20 Motorsport: _____

A. CHEST/THORAX


Measure around chest under armpit, roughly at nipple height, keep arms down by your sides.



CM:

B. WAIST CIRCUMFERENCE


Run tape measure around your waist horizontally, keep arms at your sides. Use the natural waistline just below the belly button height as pictured. Use a 2nd tape to measure back length (M) & External leg (H) whilst the waist tape is still in place



CM:

C. PELVIS CIRCUMFERENCE


Run tape measure around your pelvis at the widest point, around 18-20cm under your waist point. Keep your arm by your sides.



CM:

D. THIGH CIRCUMFERENCE


Run tape measure around your thigh horizontally, keep arms at your sides. Measure around the widest part around 10cm below the crotch.



CM:

E. SHOULDER WIDTH


With your arms at your sides, run the tape measure from bone to bone across the widest part of your shoulders. Keep the tape taut in order to obtain a accurate measurement.



CM:

F. SLEEVE LENGTH


Measure from the shoulder bone down to your wrist bone with your arm slightly bent.



CM:

G. FRONTAL LENGTH/RISE


Hold the tape in the notch of neck and measure down to the reference stitch of the underwear. (reference stitch is where the front and back join in the seam under your crotch) Always keep the tape under tension in a vertical position.



CM:

H. EXTERNAL LEG LENGTH


Measure from the reference waist point (see B) down to the top of your external ankle bone vertically keeping the tape taut.



CM:

L. INSIDE LEG LENGTH


Run tape vertically from crotch to the top of your internal ankle bone.



CM:

M. BACK LENGTH


Run the tape from the lower neck vertebra to the reference waist point (see B) the lower neck vertebra is around where the collar seam of your shirt would be.



CM:

N. NECK CIRCUMFERENCE


Run the tape around your neck and close the circle, if you want a little more room here please add 1cm to your actual measurement.



CM:

O. BICEP CIRCUMFERENCE


Measure around the widest point of the biceps, if you have a large difference between relaxed and tensed biceps please indicate both measurements.



CM:

P. CALF CIRCUMFERENCE

Run the tape around your calf want a little more room here please add 1cm to your actual measurement.



CM:

SUIT FITTING:


- SLIM FIT CUT NO EXTRA ADDED
- STANDARD FIT 2-4CM ADDED
- LOOSE FIT 5-10CM ADDED

WAIST:

- NORMAL




- ACTION BACK WITH STRETCH RECOMMENDED




STITCHING:


- NONE 1 LAYER ONLY



- BOX RECOMMENDED





- DIAMOND



BOOT CUFF:

- NASCAR BOOT CUFF
- KNITED CUFF



Please make sure all your measurements are correct!

We highly recommend having someone to help measure you.

Do not add extra to any measurements, use the Suit Fitting box on the right.

By signing, you agree that you've double checked all measurements and will be responsible for any errors and alterations required due to incorrect measurements.

If you are unsure on anything, please contact us and we'll be happy to help: azhar@prowear.co.nz

NAME: _____

SIGNATURE: _____

DATE: _____